

SYNTHESIS OF TIN DISELENIDE (SnSe₂) NANOPARTICLES FOR PHOTODETECTOR APPLICATIONS

FINAL REVIEW OF THE MINOR PROJECT



Ms. J.Kalaivani,

Reg. No.: RA2011023010003,

B.Tech, Nanotechnology,

Department of Physics and Nanotechnology,

SRM IST, Kattankulathur.

Under the guidance of


Dr. E. Senthil Kumar,

Research Associate Professor,

Nanotechnology Research Center, SRM-IST,

Kattankulathur.

CRYSTAL STRUCTURE




- Tin diselenide is a **Group-IV dichalcogenide**
- SnSe₂ is trigonal omega structured and crystallizes in the trigonal $\bar{P}3m1$ space group.
- SnSe₂ has **hexagonal symmetry** with repeating **Se–Sn–Se** units, and the two interacting layers are interconnected together via van der Waals forces, forming a stable **“three-layer” structure**. These layers are weakly coupled along the c axis by **van der Waals forces**.
- This property enables the formation of **10 polytypes** by lattice relaxations for the repetition unit along the stacking axis.

PROPERTIES

- SnSe₂ crystals have a **high carrier mobility of $8.6 \text{ cm}^2 \text{ V}^{-1} \text{ s}^{-1}$** at room temperature.
- SnSe₂ is a **n-type** conductivity material.
- SnSe₂ is an **indirect band gap (1.0 eV)** semiconductor with
 - Absorption coefficient of **$1.3 \times 10^4 \text{ cm}^{-1}$**
 - Carrier mobility of **$233 \text{ cm}^2 \text{ V}^{-1} \text{ s}^{-1}$**
 - Carrier concentration varies from **10^{17} – 10^{19} cm^{-3}**

EXPERIMENTAL METHOD



Add 1.05 gm of $\text{SnCl}_4 \cdot 5\text{H}_2\text{O}$ dissolve it in a 30 ml of DI water in a clean 100 ml beaker and make it as two separate solutions A and B.

Add 0.473 gm of Selenium metal powder and dissolve it in a 30 ml of DI water in a clean 100 ml beaker and make it as two separate solutions C and D.

We have taken as 1:2 and 1:3 ratios of $\text{SnCl}_4 \cdot 5\text{H}_2\text{O}$ and Selenium metal powder.

Place these 4 beakers on the hotplate stirrer & stirring takes place at a 500°C for 15 mins.

EXPERIMENTAL METHOD

For beaker C add 5 ml of $\text{N}_2\text{H}_4\cdot\text{H}_2\text{O}$ (Hydrazine hydrate) as a drop wise solution into the Selenium metal powder solution for 15 mins & it turned out into black color solution.



Now, add the black color solution as drop wise into the $\text{SnCl}_4\cdot 5\text{H}_2\text{O}$ which is Beaker A.



For Beaker D add 2gm of NaOH as reducing agent to the Selenium metal powder solution for 15 mins.



Then, add 5 ml of $\text{N}_2\text{H}_4\cdot\text{H}_2\text{O}$ as a dropwise solution into the Beaker D for 15 mins & it turned into brown color.



Now, beaker D Selenium metal powder solution as drop wise into the beaker B.
Then, transfer these mixtures to a 100ml Teflon lined two different stainless autoclave.

EXPERIMENTAL METHOD

The two sealed autoclave was heated at 180°C for 24 and 48 hours in a furnace and cooled naturally.

Autoclave with NaOH + N₂H₄.H₂O – it had the reddish color solution with black precipitate



Autoclave with N₂H₄.H₂O – it had the black color solution & precipitate



Centrifuge at 3000 rpm for 10 minutes each with 4 times DI water rinse & 1 time ethanol rinse.





Disperse the centrifuge tubes before loading it into the Centrifuge Machine




These products tubes were covered in aluminum foil kept in a beaker & dried at 80 °C for 24 hours in hot air oven.



BALANCED EQUATION:



Black ppt with reddish solution




Black ppt with clear solution

X-Ray Diffraction SnSe_2

(c) Growth hour – 48 hours,
Ratio 1:3





(b) Growth hour – 48 hours,
Ratio 1:2

(a) Growth hour – 24 hours,
Ratio 1:2




SEM CHARACTERIZATION




**SnSe_2 with NaOH
& Hydrazine
hydrate, Growth
hour – 24 hours**



EDS SPECTRUM







EDS MAPPING







Element	SnSe ₂	SnSe ₂	SnSe ₂	SnSe ₂	SnSe ₂
	Net Counts	Weight %	Atom %	Atom % err	Chemical Formula
Se K	13901	53.67	63.52	1.60	Se
Sn L	71942	46.33	36.48	0.22	Sn
		100.00	100.00		




**SnSe₂ with
Hydrazine hydrate,
Growth hour – 48
hours**




**SnSe₂ with
Hydrazine hydrate,
Growth hour – 48
hours**






SnSe_2 with Hydrazine hydrate, Growth hour – 48 hours



EDS SPECTRUM



EDS MAPPING




Element	Extracted Spectrum	Extracted Spectrum	Extracted Spectrum	Extracted Spectrum	Extracted Spectrum
	Net Counts	Weight %	Atom %	Atom % err	Chemical Formula
Se K	63650	51.44	61.42	0.71	Se
Sn L	361558	48.56	38.58	0.15	Sn
		100.00	100.00		

UV ABSORPTION SPECTRUM

(a) Growth hour – 24 hours, Ratio 1:2


— SnSe₂



Band gap (E_g) 1.50 eV
approximately

UV ABSORPTION SPECTRUM

(b) Growth hour – 48 hours, Ratio 1:2




Band gap (E_g) 1.15 eV
approximately

UV ABSORPTION SPECTRUM

(c) Growth hour – 48 hours, Ratio 1:3

— SnSe₂



Band gap (E_g) 1.20 eV
approximately

Energy(eV)

Thank
you!